APRS USB DONGLE FOR A FIXED STATION

MASTER-APRS

Plug it into 5V USB, connect it to Wi-Fi, and it beacons your station to the APRS network around the clock.



APRS icon
Pick the icon your station shows on the map.

APRS SSID
Choose the SSID for your station.

Wi-Fi connectivity
Easy Wi-Fi setup and a reliable connection.

Beacon text
Set your own beacon message.

5V DC power
Works on 5V DC from any USB port.

Plug and play
Just plug it in and get started.

Pre-set for APRS
Ready for APRS operation.

Runs 24/7
Built for stable, continuous use.

Low power
Low consumption, high performance.

Quick setup

1. Plug it into 5V USB. It starts its own setup Wi-Fi.
2. Connect your phone to it and open 192.168.4.1.
3. Enter your Wi-Fi, callsign, SSID, icon and beacon text.
4. Tap Save & Reboot. It starts beaconing.

SETUP WI-FI

Wi-Fi	`MASTER-APRS Wx`
Password	`mastersetup`
Open	`192.168.4.1`

Interested? Message me.
Scan the code to message me on WhatsApp.

+91 73884 07388
vu2rcy+social@gmail.com
vu2rcy.com/products/master-aprs