RECEIVE-ONLY APRS IGATE

MASTER-APRS IGATE-Rx

Receives 1200-baud AFSK APRS packets from a VHF radio, decodes them, and forwards them to APRS-IS over Wi-Fi.



1200 baud AFSK
Receives APRS packets from your radio.

AX.25 decoding
Decodes the packets it receives.

APRS-IS over Wi-Fi
Forwards received packets to APRS-IS.

Web configuration
Easy Wi-Fi setup from a browser.

Status lights
Wi-Fi, DCD and Rx indicators.

5V DC
Runs on a 5V DC supply.

VHF radio in
Receives from your VHF radio.

Wi-Fi
Straight to APRS-IS.

Receive only
Listens and forwards.

Audio cable
Works with a suitable audio connection cable.

How it works

VHF radio
↓
MASTER-APRS IGATE-Rx
↓
Wi-Fi
↓
APRS-IS

Works with VHF radios using a suitable audio connection cable.

Interested? Message me.
Scan the code to message me on WhatsApp.

+91 73884 07388
vu2rcy+social@gmail.com
vu2rcy.com/products/master-aprs-igate-rx