

USER MANUAL

MASTER-CLOCK

Connect it to Wi-Fi once and it keeps accurate time on its own.

SETUP WI-FI NETWORK

Wi-Fi `Clock-Config`
Open `192.168.4.1`

Setup

1. Power on the clock from USB. On first use, it starts its own setup Wi-Fi network.
2. On your phone or computer, connect to the Clock-Config Wi-Fi network.
3. Open a browser and go to 192.168.4.1 if the setup page doesn't open on its own.
4. Select your home or office Wi-Fi network, enter its password, then save.
5. The clock reconnects and syncs the time automatically. No further setup needed.

To switch it to a different Wi-Fi network later, power-cycle the clock and repeat these steps.

Need help? Message me.
Scan the code to message me on WhatsApp.

+91 73884 07388
vu2rcy+social@gmail.com
vu2rcy.com/products/master-clock