

NTP WiFi Digital Clock — User Manual

Connect it to Wi-Fi once and it keeps accurate time on its own.



Setup network

Name: **Clock-Config** Address: **192.168.4.1**

1. Power on the clock. On first use, it starts its own setup Wi-Fi network.
2. On your phone or computer, connect to the **Clock-Config** Wi-Fi network.
3. Open a browser and go to **192.168.4.1** if the setup page doesn't open on its own.
4. Select your home or office Wi-Fi network and enter its password, then save.
5. The clock reconnects and syncs the time automatically — no further setup needed.

To switch it to a different Wi-Fi network later, power-cycle the clock and repeat this process.